

Trailer Safety Instructions

Connecting the trailer to the tow vehicle

1. Connect the trailer coupling to the tow vehicle towball
2. Ensure that tow vehicle towball and the trailer coupling are the same size (ie. 1"7/8 or 50mm)
3. Check that the coupling is property secured to the towball by the pin being correctly in place
4. Connect the safety chain/s to the tow vehicle
5. Connect the light connection lead to the tow vehicle
6. Ensure the jockey wheel (if any) is correctly positioned in the horizontal position
7. Ensure the hand brake is released (if any) and that the reversing latch is out of the reverse position